

CC3100 Mode Config Application

Overview and application details

[Return to CC31xx & CC32xx Home Page](#)

This sample application demonstrates how to configure CC3100 device in **STATION** or **Access Point** mode. This application uses host-driver APIs to configure the device in either of these two modes and shouldn't be confused w/ **Force AP Mode** which is used to force CC3100 to wake-up in AP mode and run with pre-defined configurations.

Note: This wiki page is only applicable for **CC3100-SDK v1.0.0** and upward releases. For documentation on older SDKs' examples, refer corresponding file in `<cc3100-sdk-installation-location>\cc3100-sdk\docs\examples\`

Source Files briefly explained

i. main - Configure the station/AP mode, initialize the device and in station mode connects to AP.

Usage

Prerequisite: This application requires an access-point with internet connectivity

- Connect the board to a Windows-PC and configure the terminal-program for seeing the logs - [CC31xx_&_CC32xx_Terminal_Setting_Wiki^[1]] has detailed instructions for configuring the terminal-program
- Define `__CONFIGURE_AP__` for configuring CC3100 in AP mode. If this macro is undefined, CC3100 will be configured in STA mode
- Edit `sl_common.h` and set values for below macros:

1. In STA mode, edit following parameters to establish connection w/ an AP.

```
#define SSID_NAME          "<ap-name>"
#define SEC_TYPE           SL_SEC_TYPE_OPEN
#define PASSKEY            " "
```

2. In AP mode, CC3100 will come-up in AP mode w/ below credentials.

```
#define SSID_AP_MODE       "cc3100_ap"
#define PASSWORD_AP_MODE   " "
#define SEC_TYPE_AP_MODE   SL_SEC_TYPE_OPEN
```

- Build and launch the application
- See the self explanatory logs on the terminal-program's console. On success, below message will be displayed on the terminal

Note: : User needs to reconfigure the device in 'Station-Mode' for executing other sample applications. Refer function `configureSimpleLinkToDefaultState` in this example's `main.c` for configuring the device in 'Station-Mode'.

Limitations/Known Issues

None

References

[1] http://processors.wiki.ti.com/index.php/CC31xx_&_CC32xx_Terminal_Setting

Article Sources and Contributors

CC3100 Mode Config Application *Source:* <http://processors.wiki.ti.com/index.php?oldid=227192> *Contributors:* A0131814, A0132173, A0221015, Codycooke, Malokyle, SarahP

Image Sources, Licenses and Contributors

File:Cc31xx_cc32xx_return_home.png *Source:* http://processors.wiki.ti.com/index.php?title=File:Cc31xx_cc32xx_return_home.png *License:* unknown *Contributors:* A0221015